

Televisions											
A											
ACME	003										
ADA	028										
ADC	012	099									
ACURA	022										
ADMIRAL	013	014	015	032	062	121					
ADYSON	016										
AGAZI	015										
AGB	136										
AIKO	016	017	022								
AIWA	100										
AKAI	019	021	022	023	024	064	081	082	083	146	
	154	182									
AKIBA	024										
AKITO	038										
AKURA	015	024	028	084							
ALBA	016	022	024	040	041	081	099	175	182		
ALBIRAL	050										
ALKOS	177										
ALLORGAN	033	039									
ALLSTAR	064										
AMPLIVISION	016										
AMSTRAD	015	022	024	026	043	081	082	084	087	121	
	136										
ANAM	022	078	122								
ANGLO	022										
ANITECH	015	022	028	056	122						
ANSONIC	022	027									
ARCAM DELTA	016										
ARC EN CIEL	058	139	152								
ARISTONA	028	064	182								
ARTHUR MARTIN	171										
ASA	013	029	030	031	062	123					
ASBERG	056	064									
ASTRA	022										
ASUKA	015	016	024								
ATLANTIC	016	033	034	064	182						
ATORI	022										
AUDIOSONIC	016	022	024	033	064	152	182				
AUDIOTON	016										
AUSIND	056										
AUTOVOX	013	015	016	033	056	070	114	138			
B											
BAIRD	124	152									
BANG & OLUFSON	013										
BASIC LINE	022	024	064								
BASTIDE	016										
BAUR	089	131	145	154	162	182					
BEKO	020	096									
BEON	064	182									
BEST	126	127									
BESTAR	064	128									
BINATONE	016										
BLACK STAR	142										
BLAUPUNKT	021	113	148								
BLUE SKY	024										

BLUE STAR	133									
BONDSTEC	142									
BOOTS	016	038								
BPL	133									
BRANDT	049	058	059	139	140	152				
BRION VEGA	013	064	070	182						
BRITANNIA	016									
BRUNS	013	020	052							
BSR	039	144								
BTC	024									
BUSH	022	024	032	037	038	040	041	045	064	081
	097	128	133	144	145	152	180	182	184	
C										
CAPSONIC	015									
CARREFOUR	040									
CASCADE	022									
CATHAY	064	182								
CENTURION	064	182								
CENTURY	013									
CGE	056	142	144							
CIMLINE	022	041								
CITY	022									
CLARIVOX	050	052	182							
CLATRONIC	015	016	022	024	043	056	064	096	142	
CONCORDE	022									
CONDOR	016	034	064	096						
CONTEC	016	022	040	042	043					
CONTINENTAL EDISON	049	058	059	124	139	152				
COSMEL	022									
CROSLEY	013	056	142	144						
CROWN	022	056	064	096	127	134	182			
CS ELECTRONICS	016	024	142							
CTC	142									
CTC CLATRONIC	027									
CYBERTRON	024									
D										
DAEWOO	016	016	022	064	128					
DAINICHI	024									
DANSAI	015	064	182							
DATSURA	134									
DAYTON	022									
DE GRAAF	019	032	046							
DECCA	016	023	038	043	064	105	136	182		
DESMET	064	182								
DIXI	022	052	064	182						
DTS	022									
DUAL	016	102	138	139	144	152				
DUAL-TEC	016	022	144							
DUMONT	013	016	027	030	031					
DYNATRON	064	182								
E										
ELBE	050	121	170							
ELCIT	013									
ELECTRO TECH	022									
ELECTA	133									
ELIN	016	029	031	064	182					
ELITE	024	034	064							

ELMAN	027	144								
ELTA	022									
EMERSON	013	140	154							
ERRES	028	064	182							
ETRON	022									
EURO-FEEL	015									
EUROMANN	015	016	016	064	127					
EUROPHON	016	027	038	064	085	136	144			
EXPERT	033									
F										
FENNER	022	128								
FERGUSON	048	049	050	063	065	094	108	124	140	176
	182									
FIDELITY	016	032	081	108	109					
FINLANDIA	019	032	123	141						
FINLUX	013	023	027	029	030	031	056	064	123	136
	144	170	180	182						
FIRST LINE	016	022	039	064	075	142				
FISHER	013	016	019	031	040	042	052	053	096	103
	144									
FLINT	064	161								
FORGESTONE	108									
FORMENTI	013	014	016	034	043	138	144	146	182	
FORTRESS	013	014								
FRONTECH	015	022	032	062	081	131	142			
FUJITSU	023	033								
FUNAI	015	039								
G										
GALAXI	096									
GBC	022	040	144							
GEC	016	023	054	062	064	136	145	154	182	
GELOSO	022	032	144							
GENERAL TECHNIC	022									
GENEXXA	024	062	064							
GOLDSTAR	016	022	025	032	064	106	142	144		
	182									
GOODMANS	015	022	023	040	041	064	081	106	124	128
	140	166	182							
GORENJE	096	127								
GPM	024									
GRAETZ	062	154	155							
GRANADA	016	019	023	032	040	044	053	056	064	067
	077	136	140	141	146	147	151	182		
GRANDIN	022	024	133	182						
GRUNDIG	021	030	056	104	114	129	130	148	149	
H										
HALIFAX	015	016								
HAMPTON	016									
HANSEATIC	016	020	022	034	039	040	064	086	131	144
	154	162	182							
HANTAREX	022	136								
HCM	015	016	022	087	133					
HIFIVOX	152									
HINARI	019	022	024	040	056	064	150	182		
HISAWA	024	133	161							
HITACHI	016	023	029	032	036	040	046	054	057	058
	059	060	061	062	131	136	144	145	151	

	152	153	154	155																
HOSHAI	024																			
HORNYPHON	064																			
HUANYU	016	128																		
HYGASHI	016																			
HYPER	016	022	142	144																
HYPSON	015	016	064	133	182															
I																				
ICE	015	016	022	024	064	081														
IMPERIAL	056	062	064	096	142	144														
INDESIT	037	114																		
INDIANA	064	182																		
INGELEN	062																			
INGERSOL	022																			
INNO HIT	016	022	023	024	064	106	136	182												
INNOVATION	015	022	074	080	081	100	124	128	184											
INTERBUY	022	122	142																	
INTERFUNK	013	028	062	064	142	152	154	162	182											
INTERVISION	015	016	027	122																
IRRADIO	022	024	064	081	182															
ISUKAI	024																			
ITC	016	144																		
ITS	024	064	081	133																
ITT	022	062	074	145	146	147	154	155	156											
J																				
JEC	177																			
JVC	040	064	081	094																
K																				
KAISUI	016	022	024	133																
KAMOSONIC	016																			
KAMP	016																			
KAPSCH	033	062																		
KARCHER	016	022	029	050	182															
KENDO	027	032	041	121																
KENNEDY	033	144																		
KINGSLEY	016																			
KNEISSEL	187																			
KOLSTER	064																			
KONKA	024																			
KORPEL	064	182																		
KORTING	013	034																		
KOYODA	022																			
KTV	016																			
KURO	134																			
KYOTO	050																			
L																				
LENCO	022																			
LENOIR	016	022																		
LESA	142																			
LEYCO	015	023	039	064	182															
LIESENK	182																			
LIFETEC	015	022	074	080	081	100	124	128	184											
LOEWE OPTA	013	064	162	182																
LOGIK	043																			
LUMA	032	033	064	182																
LUX MAY	064																			
LUXOR	016	032	060	106	114	145	151	154												

	159									
M										
M-ELECTRONIC	016	022	029	031	049	062	064	081	103	122
	123	128	152	182						
MAGNADYNE	013	027	136	142	144	182				
MAGNAFON	016	027	056	085	136					
MAGNUM	015	022	074	080	081	100	124	128	184	
MANDOR	015									
MANESTH	015	016	034	041	064	182				
MARANTZ	064	182								
MARELLI	013									
MARK	064	182								
MATSUI	016	017	022	023	026	032	038	039	040	041
	043	064	081	097	104	136	160	161	177	
	182	186								
MATSUSHITA	078									
MCMICHAEL	054									
MEDIATOR	028	064	182							
MEDION	015	022	074	080	081	100	124	128	184	
MEMOREX	022									
MEMPHIS	022	023	126							
METZ	013	088	093	148	164	165				
MICROMAXX	015	022	074	080	081	100	124	128	184	
MICROSTAR	015	022	074	080	081	100	124	128	184	
MINERVA	030	114	148							
MINOKA	064									
MITSUBISHI	013	040	043	064	067	068	073	114	148	162
	183									
MIVAR	016	056	086	106	136					
MOTION	056									
MTC	145	162								
MULTI SYSTEM	182									
MULTITECH	016	022	027	032	040	056	058	142		
	144	182								
MURPHY	016	031	146							
N										
NAD	154									
NAONIS	032	121								
NATIONAL	077	114								
NEC	040	069								
NECKERMANN	013	016	021	032	064	096	131	145	182	
NEI	064	081	126	182						
NESCO	142									
NEWTECH	022	064								
NEW WORLD	024									
NICAMAGIC	016									
NIKKAI	015	016	023	024	064	177	182			
NOBLIKO	016	027	030	056						
NOGAMATIC	152									
NOKIA	062	074	076	145	145	147	154	155	156	
NORDMENDE	037	049	058	059	062	064	070	124	139	
	140	152								
O										
OCEANIC	062	154	155							
OKANO	096									
ONCEAS	016									
ONWA	082									

ORBIT	064									
ORION	022	026	034	039	041	043	064	075	088	097
	108	136	155	160	182	184				
OSAKI	015	016	017	023	024	087	178			
OSO	024									
OSUME	023	042								
OTTO VERSAND	014	016	021	034	040	064	089	124	131	
	133	134	144	145	152	154	162	182		
P										
PAEL	016									
PALLADIUM	016	025	096							
PANAMA	015	016	022	178						
PANASONIC	062	077	078	079	080	114	137	154	155	164
	165									
PATHE CINEMA	016	034	050	086	144					
PATHE MARCONI	050	058	059	139	152					
PAUSA	022									
PERDIO	017	023	034							
PHILCO	013	056	142	144						
PHILHARMONIC	016	178								
PHILIPS	013	016	028	051	054	056	064	101	102	108
	124	128	144	154	162	168	182			
PHOENIX	013	064	182							
PHONOLA	013	028	064	182						
PIONEER	049	062	064	152	182					
PLANTRON	015	064								
POPPY	022									
PRANDONI-PRINCE	032	136	154							
PRECISION	016	178								
PRIMA	022	062								
PRINZ	060									
PROFEX	022	056	154							
PROFI-TRONIC	064									
PROLINE	023	028	064	075						
PROTECH	015	016	022	027	064	126	142	144	145	
	178	182								
PYE	028	064	081	182						
PYMI	022									
Q										
QUASAR	142									
QUELLE	015	016	029	030	031	039	043	064	089	142
	144	148	154	162	182					
QUESTA	040									
R										
RADIOLA	028	051	064	182						
RADIOTONE	020	064								
RADIOMARELLI	013	136	142							
RADIONETTE	029	031								
RANK	030	040								
RBM	030									
RCA	044									
REDIFFUSION	154									
REVOX	064	182								
REX	015	032	033	062	121	170				
RFT	013	020	052							
R-LINE	064	182								
ROADSTAR	015	022	024							

ROBOTRON	013									
RTF	013									
S										
SABA	013	049	058	059	062	124	136	139	140	152
	154	155								
SACCS	050									
SAISHO	015	016	022	026	041	043	108	136		
SALORA	032	060	062	106	121	131	134	141	144	145
	147	151	154							
SAMBERS	027	056	085	136						
SAMSUNG	015	016	022	023	043	064	096	106	117	118
	178	182	185							
SANDRA	016									
SANSUI	064									
SANYO	016	019	023	029	031	040	042	043	044	
	052	053	056	086	140	144	147	174		
SBR	028	054	108	182						
SCHAUB LORENZ	062	154	155							
SCHNEIDER	016	024	051	064	081	084	103	138	144	
	152	182								
SEG	015	016	027	040	052	056	142	144		
SEI-SYNUDYNE	013	026	027	039	062	088	136			
SELECO	032	033	040	062	121	144	170			
SENCORA	022									
SENTRA	177									
SHARP	014	018	040	042						
SHORAI	039									
SIAREM	013	027	136	144						
SICATEL	050									
SIEMENS	021	042	148							
SIERRA	028	064								
SILVER	040									
SINGER	013	027	142	144						
SINUDYNE	013	026	027	039	041	088	144	182		
SKANTIC	062	151	159							
SOGERA	034									
SOLAVOX	062									
SONITRON	019	147								
SONOKO	015	016	022	064	182					
SONOLOR	019	062								
SONTEC	064	182								
SONY	022	023	040	042	043	089	140	178		
SOUND & VISION	024	027								
SOUNDWAVE	064	182								
STANDARD	016	022	024	034	064	178				
STENWAY	133									
STERN	032	033	062							
SUNKAI	022	039	075	097						
SUNWOOD	022	064								
SUPERLA	016									
SUPERTECH	131									
SUPRA	022									
SUSUMU	024									
SUTRON	022									
SYDNEY	016	178								
SYSLINE	182									
T										

TANDBERG	093									
TANDY	014	016	023	024	061	062	178			
TASHIKO	016	032	040	054	069	141	178			
TATUNG	016	023	038	064	105	136	178	182		
TCM	015	022	074	080	081	100	124	128	184	
TEC	016	022	061	142	144	178				
TECHNICS	078									
TECHNISAT	052									
TECNEMA	034									
TELEAVIA	049	058	124	139	152					
TELEFUNKEN	048	049	063	064	065	091	092	114	115	124
	139	140	152	176						
TELEMEISTER	034									
TELETECH	022	126	142							
TELETON	016	033	093	131	145	178				
TELEVIDEON	034									
TEVION	015	022	074	080	081	100	124	128	184	
TENSAI	022	024	031	034	039	064				
TESMET	064									
TEXET	016	178								
THOMSON	016	049	058	059	063	064	065	114	115	124
	139	140	152	176	179					
THORN	023	031	048	050	067	094	108	124	140	154
	162	177	182							
TOKAI	023	064								
TOKYO	016									
TOMASHI	133									
TOSHIBA	030	040	095	177						
TOWADA	062	144								
TRIDENT	178									
TRIUMPH	026	095	136							
U										
UHER	033	034	056	062	064					
ULTRAVOX	013	016	027	142	144	146				
UNIVERSUM	015	029	031	064	096	115	123	127	142	144
	182									
UNIVOX	050									
V										
VESTEL	062	064	182							
VEXA	022	182								
VICTOR	040	064	078							
VIDEOLOGIQUE	016	024								
VIDEOSAT	142									
VIDEO SYSTEM	064									
VISIOLA	016									
VISION	034	064								
VISOREX	109									
VISTAR	061									
VORTEC	064	182								
VOXSON	013	032	056	062	064	121				
W										
WALTHAM	016	050	061	151	178					
WATSON	034	064	182							
WATT RADIO	016	027	050	144						
WEGA	013	040								
WELTBlick	064	182								
WESTON	144									

WHITE WESTINGHOUSE	016	027	034	056	182					
Y										
YOKO	015	016	022	024	064	178	182			
YORX	024									
Z										
ZANUSSI	032	033	121							
VCR'S										
A										
AIWA	013	014	015	016	031					
AKAI	015	017	019	020	021	022	083			
AKIBA	058									
AKURA	015	027	058							
ALBA	016	028	029	030	031	058				
ALLORGAN	094									
AMSTRAD	014	036	037							
ANITECH	058									
ASA	039	040								
ASUKA	014	039	040	058						
B										
BAIRD	014	015	017	028	041	042				
BASIC LINE	016	028	058							
BAUR	040	046								
BESTAR	028									
BLACK PANTHER LINE	028									
BLAUPUNKT	040	043	044	045	046	054	059	087	092	157
BRANDT	086	088								
BRION VEGA	047									
BROKSONIC	059									
BUSH	016	028	029	030	031	058	071			
C										
CGE	014	015								
CIMLINE	016	058								
COMBITECH	031									
CONDOR	028									
CROWN	028	058								
D										
DAEWOO	028	048	057	102						
DANSAI	058									
DAYTRON	028									
DE GRAAF	040	049								
DECCA	014	015	040							
DUAL	015	040								
DUMONT	014	040	049							
E										
ELIN	035									
ELTA	058									
EMERSON	072									
ESC	028									
ETZUKO	058									
F										
FERGUSON	015	042	054	061	064	077	088			
FIDELITY	014									
FINLANDIA	040	049								
FINLUX	014	015	017	040	049	069	081			
FIRST LINE	016	039	048	049	058	081				

FISHER	062										
FLINT	016										
FORMENTI-PHEONIX	040										
FUJITSU	014										
FUNAI	014										
G											
GALAXY	014										
GBC	058										
GEC	040										
GELOSO	058										
GENERAL TECHNICS	016	052	083	094							
GOLDHAND	058										
GOLDSTAR	014	039									
GOODMANS	014	028	035	039	042	058	065	066			
GRAETZ	015	047									
GRANADA	023	040	049	054	068						
GRANDIN	014	028	039	058							
GRUNDIG	026	040	043	046	053	054	055	056	058	059	
	069	071	073								
H											
HANSEATIC	039	040									
HCM	058	071									
HINARI	016	031	058	071	072						
HISAWA	016										
HITACHI	014	015	049	051	087						
HYPSON	016	058									
I											
IMPERIAL	014										
INNOVATION	016	052	083	094							
INNO HIT	028	035	040	058							
INTERBUY	039										
INTERFUNK	040										
INTERVISION	014										
IRRADIO	039	058									
ITT	015	017	047	075	076						
ITV	028	039									
J											
JVC	015	076	077	078	079	080					
K											
KAISUI	058										
KARCHER	040										
KENDO	016	017	019	083							
KENWOOD	015										
KORPEL	058										
L											
LENCO	028										
LEYCO	058										
LIFETEC	016	052	083	094							
LOEWE	045										
LOEWE OPTA	039	040	054								
LOGIK	035	058									
LUXOR	017	065	081								
M											
MANESTH	048	058									
MARANTZ	040	054	059	065	082						
MATSUI	016	031	039	072	084						
M ELECTRONIC	014										

MEDIATOR	040									
MEDION	016	052	083	094						
MEMOREX	014	023	039	062						
MEMPHIS	058									
METZ	044	045	046	054	056	059				
MICROMAXX	016	052	083	094						
MICROSTAR	016	052	083	094						
MIGROS	014									
MINERVA	046	054								
MITSUBISHI	014	040	077	081						
MULTITECH	014	040	058							
MURPHY	014									
N										
NATIONAL	043	045								
NEC	015	077	082							
NECKERMANN	015	040	047	072						
NEI	040									
NESCO	058									
NIKKAI	085									
NOKIA	015	017	023	035	047	075				
NORDMENDE	015	076	077	086	088					
O										
OCEANIC	014	015	023							
OKANO	016	083								
ORION	016	029	031	066	072	084				
ORSON	014									
OSAKI	014	039	058							
OTTO VERSAND	040	046								
P										
PALLADIUM	015	039	054	058	083					
PANASONIC	043	044	045	052	097					
PATHE CINEMA	084									
PATHE MARCONI	015									
PENTAX	049									
PERDIO	014									
PHILCO	082									
PHILIPS	040	054	073	076	087	098				
PHONOLA	040									
PIONEER	040	077								
PORTLAND	028									
PRINZ	014									
PROFEX	058									
PROLINE	014	071								
PYE	040									
Q										
QUELLE	014	040	041	046	047	054	072			
R										
RADIOLA	040									
REX	015	076								
RFT	087									
ROADSTAR	028	035	039	058						
S										
SABA	015	064	076	086	088					
SAISHO	016	031	058	072	084					
SALORA	017	075	081							
SAMSUNG	035	094	095							
SANSUI	015	027	077							

SANYO	041	062							
SAVILLE	031								
SBR	040								
SCHAUB LORENZ	014	015	017	047					
SCHNEIDER	014	016	039	040	058				
SEG	035	058							
SEI SINUDYNE	040								
SELECO	015								
SETRON	058								
SHARP	023	024	065						
SHINTOM	058								
SHIVAKI	039								
SIEMENS	039	046	054	069					
SILVA	039								
SINUDYNE	040								
SONOKO	028								
SONOLOR	023								
SONTEC	039								
SONY	032	091	092	093	096				
STANDARD	028								
STRONG	027								
SUNKAI	016								
SUNSTAR	014								
SUNTRONIC	014								
SUNWOOD	058								
T									
TAISHO	016								
TANDBERG	046	072							
TASHIKO	014	023							
TATUNG	014	015	040						
TCM	016	052	083	094					
TECHNICS	043	045							
TELEAVIA	015								
TELEFUNKEN	015	076	077	078	086	088	089	090	
TENOSAL	058								
TENSAI	014	039	058						
TEVION	016	052	083	094					
THOMSON	015	076	077	078	088	106	107		
THORN	015	084							
TOKAI	039	058							
TONSAI	058								
TOSHIBA	015	040	048	076	081	087			
TOWADA	058								
TOWIKA	058								
TRIUMPH	072								
U									
UHER	039	047							
ULTRAVOX	047								
UNITECH	035								
UNITED QUICK STAR	028								
UNIVERSUM	014	017	022	036	039	040	046	054	073
V									
VICTOR	077	078							
VIDEON	016	052	083	094					
W									
WELTBlick	039								
WHITE WESTINGHOUSE	047								

Y																		
YAMISHI	058																	
YOKAN	058																	
YOKO	035	039	058															
<u>DVD/VCR</u>																		
A																		
AKAI	117																	
D																		
DENON	112																	
G																		
GRUNDIG	118																	
H																		
HITACHI	116																	
J																		
JVC	109																	
M																		
MARANTZ	110																	
P																		
PANASONIC	112																	
PHILIPS	110	118																
PIONEER	116																	
S																		
SAMSUNG	115																	
SONY	111																	
T																		
THOMSON	108																	
TOSHIBA	110																	
Y																		
YAMAHA	112																	
<u>LASER DISC PLAYERS</u>																		
D																		
DENON	035																	
DISCO VISION	074																	
G																		
GRUNDIG	101																	
H																		
HITACHI	074																	
M																		
MITSUBISHI	101																	
N																		
NAD	101																	
P																		
PHILIPS	102																	
PHILIPS CD-V	099																	
PHILIPS CD-I	100																	
PIONEER	074	101																
R																		
RADIOLA	102																	
S																		
SONY	061																	
T																		
TELEFUNKEN	101																	
THORN	105																	

Cable Boxes																			
A																			
ANDOVER CABLEVISION	036																		
B																			
BT CABLE	058																		
C																			
CABLETIME	060	061	062	063															
CLYDE CABLEVISION	065																		
CRYPTOVISION	071																		
F																			
FILMNET CABLECRYPT	087																		
FILMNET COMCRYPT	087																		
G																			
GEC	065																		
GRUNDIG	028	096																	
J																			
JERROLD	107	167																	
M																			
MOVIE TIME	164																		
O																			
OAK	125																		
P																			
PIONEER	028	130																	
S																			
SALORA	132																		
SAMSUNG	130																		
SATBOX	135																		
SCIENTIFIC ATLANTA	137	138	139																
STS	164																		
T																			
TELE+1	087																		
TELESERVICE	033	145																	
TUDI	055																		
V																			
VISIOPASS	100																		
VIDEOWAY	015	149																	
W																			
WESTMINSTER CABLE	058																		
Satellite Receivers																			
A																			
AKAI	013	165																	
ALBA	013	014	015	017	018	019	020	126	175										
ALDES	018	021	022																
ALLANTIDE	026																		
ALLSAT	023	025	075	165															
ALLSONIC	021	041																	
AMPERE	035																		
AMSTRAD	028	029	030	032	034														
ANKARO	021	037	041																
ANTTRON	014	025	020																
APOLLO	014																		
ARCON	028	035	037	039	040	076													
ARMSTRONG	032																		

ASAT	040	165								
AST	048	049	050							
ASTON	207									
ASTRA	013	032	040	042	043	044	045	046	115	
ASTRO	020	022	041	052	053	054				
AUDIOTON	020	075								
AURA	046									
AXIS	028	041	045	069						
B										
BARCOM	037									
BEST	037	041								
BLAUPUNKT	052									
BOCA	032	115								
BRANDT	178	179	180	187						
BRAIN WAVE	057									
BROADCAST	056									
BRUNOR	166									
BT SATELLITE	013	033	187							
BUSH	015	017	023	059	126	175				
C										
CAMBRIDGE	013	064								
CAMUNDOSAT	066									
CANAL+	182									
CHANNEL MASTER	018									
CHAPARRAL	120									
CITYCOM	015	072								
CLATRONIC	057									
CLEMENS KAMPHUS	026	104								
CNT	022									
COLUMBUS	090									
COMMLINK	021									
COMTECH	069	070								
CONDOR	041									
CONNEXIONS	051	066	067							
CONTEC	069	072								
COSAT	075									
CROWN	032									
D										
DAERYUNG	051									
DAEWOO	040									
DANSAT	023	025								
DDC	018									
DECCA	073									
DELEGA	018									
DEW	069									
DIAMOND	074									
DISKXPRESS	037	067								
DITRISTRAD	075									
DNT	051	165								
DONG WOO	114									
DRAKE	076	170								
DUAL	040									
DYNASAT	043									
E										
ECHOSTAR	038	051	077	078	080	191	192	193	194	199
EEC	026									
EINHELL	014	021	026	030	032					

ELEKTA	022									
ELTA	014	019	041	075	165					
EMANON	014									
EMME ESSE	041	043	059	104						
EP SAT	015									
EURODEC	082	083								
EUROPA	043									
EUROSAT	032									
EUROSKY	032	041	043							
EUROSPACE	081									
EUROSTAR	019	032								
EXATOR	013	014	020							
F										
FERGUSON	015	023	025	059	082	084	085	086		
FIDELITY	028	030								
FINLANDIA	015									
FINLUX	013	015	042	088	093	100				
FINNSAT	069	082								
FORCE	190									
FRANCE SATELLITE/TV	090									
FREECOM	014	089								
FTE	033	035	070	109						
FUBA	014	037	041	044	051	052	090	093	161	
	165	168								
G										
GALAXI	037									
GALAXIS	021	041	045	069	075	091	097	195	196	
GMI	032									
GOLDSTAR	089									
GOODING	096									
GOODMANS	015	095								
GRANADA	042									
GROTHUSEN	014	089								
GRUNDIG	015	030	052	059	096	098	108	163		
G-SAT	025	026								
H										
HANSEATIC	117									
HANTOR	014	057	114							
HANURI	022									
HARTING UND HELLING	026									
HELIOCOM	035									
HIGH PERFORMANCE	103									
HINARI	018	019	025							
HIRSCHMANN	026	052	099	100	101	104	168	171		
HISAWA	057									
HITACHI	015	059	150							
HOUSTON	075									
HUTH	021	024	032	056	057	069	075	104		
HUMAX	195									
I										
IMPERIAL	126	175								
INNOVATION	041	117	199	200						
INTERTRONIC	032									
INTERVISION	075									
ITT/NOKIA	015	042	059	067	100	150	157	161	168	
J										
JOHANSSON	057									

JSR	075										
JVC	013	096									
K											
KATHREIN	026	052	054	072	109	110	111	112	120	162	
	165										
KOSMOS	089	104	109	110							
KR	020										
KREISELMEYER	052										
KYOSTAR	014										
L											
LASAT	022	041	113	114	115	178	179	180			
LENCO	014	033	040	089	116						
LENG	057										
LENNOX	075										
LEYCO	013										
LIFESAT	041	117	199	200							
LIFETEC	041	117	199	200							
LION	026	081									
LORRAINE	089										
LUPUS	041										
LUXOR	030	042	150	168							
M											
MACAB	082										
MANHATTAN	015	016	022	059	075						
MARANTZ	165										
MASCOM	022	110									
MASPRO	015	059	084	096	120	171					
MATSUI	013	096	187								
MB	117										
MEDIAMARKT	032										
MEDIASAT	045	124									
MEDION	041	117	199	200							
MEGA	165										
METRONIC	014	020	021								
METZ	052										
MICROMAXX	041	117	199	200							
MICROSTAR	041	117	199	200							
MICRO TECHNOLOGY	026	046	081								
MIMTECH	118										
MINERVA	052	096									
MITSUBISHI	015	052	187								
MITSUMI	115										
MORGANS	032	115	119	165							
MULTISTAR	109	114									
MURATTO	050	089									
N											
NAVEX	057										
NEC	122	123									
NETWORK	025										
NEUHAUS	045	075	124								
NEXTWAVE	027	198									
NIKKO	032										
NIMBUS	118										
NOKIA	015	042	059	067	100	143	144	161	168		
	176	177									
NORDEMENDE	014	015	018	022	082	085	162				
NOVIS	057										

O										
OCEANIC	026	074	081							
OCTAGON	014	019	020	040	069					
OKANO	032	104	109							
OPTEX	072	075								
ORBIT	026	040	048	049						
ORBITECH	014	124	127							
ORIGO	129									
OSAT	030									
OTTO VERSAND	052									
OXFORD	013									
P										
PACE	015	023	025	052	059	084	095	121	140	
	145	172	197							
PACIFIC	074									
PALCOM	018	044	090	092						
PALLADIUM	032	096	098							
PALSAT	124									
PALTEC	044									
PANASONIC	015	059								
PANDA	015	023								
PATRIOT WORLDSAT	013									
PHILIPS	015	025	047	059	068	079	096	121	128	
	156	158	163	165	174	212	213			
PHOENIX	025	069	095							
PHONOTREND	021	075	104							
PK SAT	026									
POLYTRON	072									
PREDKI	057									
PREMIERE	075	182								
PRIESNER	032									
PROFI	116									
PROMAX	015									
PROSAT	017	018	021	126	175					
PROTEK	026	074								
PROTON	026									
PROVISION	022									
PTT TELECOM	066									
Q										
QUADRAL	018	021	041							
QUELLE	030	052								
R										
RADIOLA	165									
RADIX	051									
RAINBOW	020									
RE	118									
REDIFFUSION	123									
REDPOINT	045									
REDSTAR	041									
REVOX	118									
RFT	021	127	165							
RUEFACH	116									
S										
SABA	017	022	025	059	081	084	085	156	175	
	178	184	185	186	188					
SABRE	015									
SAGEM	082									

SAKURA	069	095								
SALORA	042	132	133	150						
SAMSUNG	014	039	099							
SAT	018	028	048	049	050	124				
SATCOM	056	117								
SATEC	025	059								
SATFORD	056									
SATMASTER	056									
SATPARTNER	014	020	022	057	089	104				
SCHWAIGER	024	025	072	111	117	188	189	198	211	
SEEMANN	013	032	045	051						
SEG	014	019	041	046	057	117	154			
SELECO	075									
SIEMENS	052									
SILVA	089									
SKARDIN	045									
SKYMASTER	021	117	199	200	201	202	203	204	205	
SKYMAX	026	165								
SKYVISION	075									
SONY	031									
SR	032	085	115							
STARION	046									
STARLAND	199									
STARRING	057									
STAR TRAK	014									
STELLA	066									
STRONG	014	020	041	067	070	102	175			
SUMIDA	032									
SUNSTAR	032	115	140							
T										
TANDBERG	082									
TANDY	103									
TANTEC	015	059	084	090	092					
TATUNG	073									
TECO	032	040	115							
TECHNILAND	056									
TECHNISAT	051	092	124	127	141	142	166			
TELANOR	018									
TELASAT	117									
TELECOM	066									
TELEFUNKEN	014	059	178	179	180	187				
TELEKA	020	032	039	051	110					
TELEMASTER	022									
TELEMAX	113									
TELESAT	117									
TELEVES	015									
TELEWIRE	075									
TENSIA	040									
THOMSON	015	085	169	187						
THORENS	074									
THORN	015	023	025	059	084	086				
TIOKO	072									
TONNA	015	056	075							
TPS	183									
TRIAD	026	048	049	050	089	146				
TRIASAT	093									
TRIAX	052	092	124	178						

TRISTAR	070									
U										
UNIDEN	147									
UNISAT	032	069								
UNITOR	037	057								
UNIVERSUM	052	088	096	100						
V										
VARIOSTAT	052									
VECTOR	026	081								
VENTANA	165									
VISIOSAT	057	075	199	206	207	208	209	210		
VORTEC	014	039	099							
V-TECH	048	049	050	128	150					
W										
WEWA	015									
WEVASAT	015	026								
WINERSAT	057									
WISI	015	048	050	051	052	146	151	152	153	
WITTENBERG	028									
WOLSEY	103									
WOORISAT	022									
Z										
ZEHNDER	022	041	050	109	111	154				
ZODIAC	020									
CD players										
A										
ADCOM	021									
AIWA	022	023	024							
AKAI	025	026	027	028						
ALBA	029									
ARCAM	030									
ASUKA	031									
AUDIOSONIC	031									
B										
BESTAR	032									
BSR	033									
BUSH	034									
C										
CARRERA	036									
CONDOR	033									
CROWN	037									
D										
DENON	038	039								
DUAL	031	040								
E										
EMERSON	021	032								
F										
FISHER	042	043								
G										
GENEXXA	032	044	045	046	047	048	049	050		
GOLDSTAR	036									
GOODMANS	051	052								
GRUNDIG	030	053								
H										
HARMON KARDON	025	054	055	056						

HITACHI	021	040	057	058	059														
I																			
INTERSOUND	031																		
J																			
JVC	060																		
K																			
KENWOOD	045	042	061	062	063														
KODAK	016																		
L																			
LINN	030																		
LUXMAN	064	065																	
M																			
M ELECTRONIC	066																		
MARANTZ	030	067	068																
MATSUI	030	069	067																
McINTOSH	070	071																	
MEMOREX	021	032	047	050															
MERIDIAN	030																		
MICROMEGA	030																		
MISSION	030																		
N																			
NAD	044	065	108	109	110														
NAIM	030																		
NAKAMICHI	072	073																	
O																			
ONKYO	013	074	075	076	077														
P																			
PANASONIC	034	078																	
PHILIPS	014	016	030	079	080														
PIONEER	046	050	126																
PROTON	030																		
Q																			
QUAD	030																		
R																			
REALISTIC	021	032	047	048															
ROADSTAR	066	079																	
ROTEL	030																		
S																			
SABA	040																		
SAE	030																		
SANSUI	014	030	082	083	084														
SCHNEIDER	030	031	033																
SCOTT	032																		
SHARP	045	085	086	087															
SIEMENS	088																		
SIGNATURE	025																		
SONY	044	089	090	091	114	121													
SUNWOOD	031																		
T																			
TANDBERG	092																		
TECHNICS	078	094																	
TELEFUNKEN	040																		
THOMSON	040																		
TOSHIBA	065	095	096																
U																			
UNIVERSUM	030																		
V																			

VECTOR RESEARCH	036										
VICTOR	060										
Y											
YAMAHA	085	093	098								
<u>Audio Amplifiers</u>											
GRUNDIG	099										
LINN	099										
MARANTZ	099										
MERIDIAN	099										
NAIM	099										
PIONEER	099										
PHILIPS	099										
QUAD	099										
YAMAHA	125										
<u>Audio Amplifier/Tuners</u>											
GRUNDIG	100										
MARANTZ	100										
PHILIPS	100	101									
SANSUI	100										
SONY	112	113									
YAMAHA	097										
<u>Audio Cassette Players</u>											
GRUNDIG	102										
MAGNAVOX	102										
MARANTZ	102										
PHILIPS	102										
SANSUI	102										
YAMAHA	097										
<u>MINI HiFi</u>											
SONY	114										
PIONEER	126										
<u>Digital Audio Tape Players</u>											
GRUNDIG	019										
MARANTZ	019										
PHILIPS	019										
<u>Philips</u>											
Video CD	013										
CD Video	014										
Camcorder	015										
CD Photo	016										
Audio Combi	017										
DBS	018										
DCC	019										
CDR	020										
<u>Stereo Receiver</u>											
Nad	108	109	110	111							

<u>Home Automation</u>										
H										
HOME AUTOMATION	014									
X										
X-10 (NEC)	013									